

## REPAIR INSTRUCTIONS :

1. The windshield and repair area should be under direct sunlight until the repair is completed.



2. Remove the glass fragments by scraping with razor blade and clean the glass with dry paper.

3. Set the suction cup support set on the windshield and make the injection centre is directly over the damage area.



4. screw the resin injection tube into the suction base and onto the windshield damage area. the injection tube must touch the damage point. Please ensure the rubber tip of the resin injection tube fully seals against surface of the damage point.



- A - Suction cup support set
- B - Resin injection tube & Pressure driver
- C - Resin bottle
- D - Razor blade
- E - Curing strip x10